




CURIO SHELVES

#P132 - Maiden, Tulips, Country Auto



#P132 - Curio Shelf

GREAT AMERICAN SCROLLSAW DOWNLOADABLE PATTERNS™




The Berry Basket © Copyright 2002 • All Rights Reserved
www.greatamericanscrollsaw.com • a division of The Berry Basket

#P132 Curio Shelves Instructions

1. Select your material from a variety of hardwoods or solid core plywood.
2. Measure each pattern piece and cut the work pieces to size accordingly. Sand as necessary.
3. Make all pattern pieces by adhering the paper patterns to the work pieces with a repositionable spray adhesive. Cut the outer shapes and any interior designs. And drill where indicated. Due to the thinner materials being used for this project, both brackets could easily be cut at the same time using the stack cutting method.
4. Remove all paper patterns. Sand where needed. The edges can be rounded by sanding or using a small roundover router bit if desired.
5. Finish as desired by dipping into a penetrating oil or simply spraying with a clear lacquer or varathane.
6. Assemble by inserting the Shelf tabs into the Bracket slots. Secure with glue, finishing nails and/or wood screws.

CURIO SHELF #P132


Description	Item	Qty	Size
Bracket	A	2	1/4" T x 6 1/2" W x 15" L
Bracket	B	2	1/4" T x 6" W x 15 3/4" L
Bracket	C	2	1/4" T x 6" W x 15" L
Shelf	D	2 or 3	1/4" T x 6 1/4" W x 15 1/4" L



Pattern overlap line


Bracket (A)

Stock: 1/4" hardwood or
plywood
Cut 2. Top pattern piece.




Bracket (B)

Stock: 1/4"
hardwood or plywood
Cut 2.
Top pattern piece.





#P132



Bracket (C)

Stock: 1/4" hardwood
or plywood
cut 2. Top pattern piece.

Use #18 x 5/8"
finishing nails if
needed



Pattern overlap line

